JVC

# COLOUR TELEVISION

# *INSTRUCTIONS*

Thank you for buying this JVC colour television.
To make sure you understand how to use your new TV, please read this manual thoroughly before you begin.

*S series:*

***AV-21LS2***
***AV-21WS3***
***AV-25LS3***
***AV-29LS2***
***AV-29WS3***

*X series:*

***AV-20NX3***
***AV-21DX3***
***AV-21FX3***
***AV-21LX2***
***AV-21WX3***
***AV-25KX3***
***AV-25LX3***
***AV-29LX2***
***AV-29WX3***

## Contents


**Safety precautions** 2
**Preparation** 3
1 Confirm which remote control you have ... 3
2 Insert the batteries into the remote control ... 3
3 Connecting the aerial and VCR ... 4
4 Connecting other devices ... 5
5 Connect the power cord to the AC outlet ... 5
6 Initial setting ... 6
**Basic operation** 7
**Remote control buttons and functions** 8
ECO SENSOR button ... 8
PICTURE MODE button ... 8
COLOUR SYSTEM button ... 8
SOUND SYSTEM button ... 8
I/II button ... 9
MUTING button ... 9
DISPLAY button ... 9
CINEMA SURROUND button ... 9
OFF TIMER button ... 10
CHANNEL SCAN button ... 10
RETURN + button ... 10
**Viewing teletext programmes** 11, 12
**Using the TV's menus** 13
Basic operation ... 13
INPUT ... 14
PICTURE TILT ... 14
VNR ... 14
COMPRESS (16:9) ... 14
AUTO SHUTOFF ... 15
CHILD LOCK ... 15
BLUE BACK ... 15
VIDEO-2 SET ... 16
Picture Adjustments ... 16
Sound Adjustments ... 16
AI VOLUME ... 17
AUTO CH PRESET ... 17
MANUAL CH PRESET ... 18
SKIP ... 19
LANGUAGE ... 19
TEXT LANGUAGE ... 19
**TV buttons and parts** 20
**Using the buttons on the TV** 22
**Troubleshooting** 23
**Specifications** Back cover



LCT1170-001B-H
0602-Ki-NIC-JMT



© 2002 VICTOR COMPANY OF JAPAN, LIMITED

# Safety precautions

## WARNING

**• To prevent fire or shock hazard, do not expose the TV to rain or moisture.**

### CAUTION

- Operate only from the power source indicated on the rear of the TV.
- Avoid damaging the power cord and mains plug. When you unplug the TV, pull it out by the mains plug. Do not pull on the power cord.
- Never block or cover the cabinet openings for ventilation. Never install the TV where good ventilation is unattainable. When installing this TV, leave spaces for ventilation around the TV more than the minimum distances shown in the diagram.




- Do not allow objects or liquid into the cabinet openings.
- In the event of a fault, unplug the TV and call a service technician. Do not attempt to repair it by yourself or remove the rear cover.
- The surface of the TV screen is easily damaged. Be very careful with it when handling the TV. Should the TV screen become soiled, wipe it with a soft dry cloth. Never rub it forcefully. Never use any cleaner or detergent on it.
- When you don't use this TV for a long period of time, be sure to unplug it.

## WARNING

*< AV-21WS3 and AV-21WX3 only >*

A removable plastic cover is fixed to the television's front Audio/Video connector. To prevent this cover from being accidentally swallowed by babies or children, remove it from the television and store it in a safe place. If the cover is swallowed seek the advice of a doctor immediately.

# Preparation

## 1 Confirm which remote control you have

Your TV comes with one of the four remote controls shown below. Functions you can operate differ depending on the type of remote control.

*<AV-21WS3/AV-25LS3 /AV-29WS3>*




*<AV-20NX3/AV-21DX3 /AV-21FX3/AV-21WX3 /AV-25KX3/AV-25LX3 AV-29WX3>*




*<AV-21LS2/AV-29LS2>*




*<AV-21LX2/AV-29LX2>*




## 2 Insert the batteries into the remote control

Correctly insert two batteries, observing the ⊕ and ⊖ polarities and inserting the ⊖ end first.

**CAUTION:**
Follow the cautions printed on the batteries.

**Notes:**
- Use AA/R6/UM-3 dry cell batteries.
- If the remote control does not work properly, fit new batteries.
  The supplied batteries are for testing, not regular use.



# 3 Connecting the aerial and VCR

- Read the manuals provided with the devices. Depending on the device, the connection method may be different from the diagrams. Also the device settings may need to change depending on the connection method.
- Turn off all the devices including the TV.
- Connecting cables are not supplied.
- When connecting monaural audio to the TV, use the L/MONO jack.
- If your TV has an S-connector, you can connect an S-VIDEO compatible device (such as an S-VHS VCR) to the S-connector with an S-VIDEO cable and enjoy the high quality picture of the S-VIDEO signal (Y/C signal). In that case, do not connect it to the TV with a video cable.
- If you connect the VCR to the TV only with an aerial cable, you should preset the video channel from the VCR to the AV channel (channel number 0) on this TV. See "MANUAL CH PRESET" on page 18 and preset it manually.

**Connecting the aerial**




**Connecting the aerial and VCR**



## 4 Connecting other devices

If you are not connecting any other devices, skip step 4 and perform step 5.

- Use the headphones with a stereo mini jack (3.5 mm in diameter). When you connect the headphones, the TV speakers go off.
- The OUTPUT terminal outputs the video and sound signals which you are viewing on the TV. You can dub them onto the VCR connected to the OUTPUT terminal.
  (The OUTPUT terminal cannot output teletext programmes, S-VIDEO signals or component video signals. Also it cannot output any signals when the TV is turned off.)
- Connect components outputting a component signal ($Y/C_B/C_R$ signal), such as a DVD player, to the VIDEO-2 terminal, and set VIDEO-2 SET function to "COMPONENT". (See page 16.)
- The following illustrations are for the AV-29LS2. Your TV's front and rear pannels may not look exactly like the illustrations.







## 5 Connect the power cord to the AC outlet

Operate only from the power source indicated on the rear of the TV.

# 6 Initial setting

When the TV is first turned on, it enters the initial setting mode, and the JVC logo is displayed. Follow the instructions on the on-screen display to perform the initial settings.

### 1 Press the Main power button on the TV.

The POWER lamp lights. After the JVC logo has been displayed, the TV automatically switches to the language setting mode.






- The JVC logo does not appear if your TV has been turned on once before. In this case, use the LANGUAGE and AUTO CH PRESET functions to perform the initial settings. For details, see pages 17 and 19.

### 2 Press the MENU ◀/▶ buttons to select language.

### 3 Press the MENU ▲/▼ buttons to select “AUTO CH PRESET”.

### 4 Press the MENU ◀/▶ buttons to start the AUTO CH PRESET function.

“ >>> ON SEARCH” is displayed on the screen.

When all the TV channels that can be received on your TV have been preset, the display goes out and the AUTO CH PRESET function operation is completed.

To stop the AUTO CH PRESET function, press the MENU ◀/▶ buttons.

- If a TV channel you want to view is not set to the channel, set it with the MANUAL CH PRESET function. For details, see page 18.

## This completes initial setting. Now you’re ready to enjoy your JVC TV.

# Basic operation

• The illustration below is for the remote control RM-C1010. Depending on the applicable models, the remote controls may not look exactly the same.




## 1 Press the POWER button to turn your TV on.

- If your TV does not turn on, press the Main power button on the TV then press the POWER button again.
- You can also turn on your TV by pressing any of the following buttons;
  - the CHANNEL –/+ button
  - the Number buttons
  - the TV/VIDEO button

## 2 Select a channel.

■ Press the CHANNEL –/+ button.

- Up/down selection cannot be selected for channels to which the SKIP has been set to "YES". See page 19.

■ Press the Number buttons to enter the channel number.

- If you want to enter a two-digit number, press the -/-- button to select the two digit mode "--", then enter the channel number.

## 3 Press the VOLUME –/+ button to adjust the sound.

## 4 To turn your TV off, press the POWER button.

- We recommend that you press the Main power button on the TV to turn the main power off if you do not plan to use your TV for a long time or if you wish to save energy.

**If the picture is not clear:**
Press the COLOUR SYSTEM button to select another colour system, see page 8.

**If the sound is not clear:**
Press the SOUND SYSTEM button to select another sound system, see page 8.

**Viewing Images from an External Device:**
Press the TV/VIDEO button to select the VIDEO mode.

- You can also use the INPUT function to select the VIDEO mode. For details, refer to page 14.

# Remote control buttons and functions

## ECO SENSOR button

You can adjust this TV so that the screen automatically adjusts to the optimum contrast according to the brightness of your room. This function reduces eye strain and the power consumption of this TV.

**Press this button to select the desired mode.**

**DIGITAL ECO SENSOR DISPLAY:**
The ECO SENSOR function switches on. In this mode, the clover mark indicating the brightness of your room is displayed for several seconds each time the brightness changes. The number of clover marks displayed on screen increases as your room becomes darker.

**DIGITAL ECO SENSOR ON:**
The ECO SENSOR function switches on. However, in this mode, the clover mark will not be displayed.

**DIGITAL ECO SENSOR OFF:**
The ECO SENSOR function switches off.

## PICTURE MODE button

You can select one of three picture adjustment settings as you like.

**Press this button to select a mode.**

**BRIGHT:**
Heightens contrast and sharpness.

**STANDARD:**
Standardizes picture adjustments.

**SOFT:**
Softens contrast and sharpness.

- Pressing this button returns all the picture settings in "MENU 4" to their default settings.

## COLOUR SYSTEM button

If the picture is not clear or no colour appears, change the current colour system to another colour system.

**Press this button to select the colour system.**




**AUTO:**
Automatic colour system selection.

- For the colour systems in each country or region, see the table "Broadcasting systems" on the back cover.
- If the picture is not normal in the AUTO mode, change the AUTO mode to another colour system.

## SOUND SYSTEM button

If the sound is not clear even when the picture appears normal, change the current sound system to another sound system.

**Press this button to select the sound system.**




- For the sound systems in each country or region, see the table "Broadcasting systems" on the back cover.
- You cannot select any sound system when in a VIDEO mode.

## ⧉⧉I/II button

*< S series only >*

You can select a sound setting for stereo broadcast programmes and bilingual programmes.

**Press this button to select a sound setting.**

⧉ : Stereo sound
I : Bilingual I (sub I) sound
II : Bilingual II (sub II) sound
⧉ : Monaural sound
**MONO** : Cancels the multi-sound function, and the sound becomes monaural.

- If you have poor reception of a stereo broadcast, you can change from stereo sound (⧉) to monaural sound (⧉) so that you can hear the broadcast more clearly and easily.
- If the multi-sound function cannot work normally due to poor signal quality, noise may be included in the sound, or the sound may change many times. If this happens, change the sound setting to MONO mode to cancel the multi-sound function.

## MUTING button

You can turn the sound off instantly.

**Press this button.**

To turn the sound on, press this button again.

## DISPLAY button

You can continuously display the current channel number or VIDEO mode on the screen.

**Press this button.**

To turn the display off, press this button again.

- When selecting a VIDEO mode with no signal, indication of the VIDEO mode becomes fixed on the screen.

## CINEMA SURROUND button

*< AV-21LS2/AV-21LX2/AV-29LS2/ AV-29LX2 does not included >*

You can enjoy an enhanced sound for a wider audience by using CINEMA SURROUND function.

**Press this button to select one of the CINEMA SURROUND mode.**

**HIGH/LOW:**
When you listen to the stereo sound, please select HIGH mode or LOW mode. You can enjoy the sound for a wider audience similar to the experience at the theatre.

- In case that you setting up the CINEMA SURROUND function to HIGH mode, there may be slight volume distortion. In case that occurs, please switch the HIGH mode to LOW mode, the effect of CINEMA SURROUND functions will be less noticeable, however, the volume distortion will be corrected.

**MONO SURROUND:**
Select the MONO SURROUND mode, when you listen to the mono sound. You can enjoy the sound for a wider audience similar to stereo sound.

**OFF:**
The CINEMA SURROUND function switches off.

## OFF TIMER button

You can set the TV to automatically turn off after a set time.

**Press this button to select the period of time.**

- You can set the period of time to a maximum of 120 minutes in 10 minute increments.
- 1 minute before the OFF TIMER function turns off the TV, "GOOD NIGHT!" appears.

To display the remaining time, press this button once.

To cancel the OFF TIMER function, press this button to set the period of time to 0.

- The OFF TIMER function will not turn off the TV's main power.

## CHANNEL SCAN button

You can quickly view all TV channels programmes that you can view on your TV, and search for the programme you want to view.

**1 Press this button to start scanning TV channels.**

The TV channel programmes are each displayed for several seconds.

- The programmes of TV channels for which the SKIP function is set to "YES" are not displayed.

**2 When you find the programme you want to view, press this button again to stop scanning.**

## RETURN + button

You can set a channel you frequently view to the Return Channel and you can view that channel at any time with one-touch.

**To set the channel to the Return Channel:**

**1 Select the channel you want to set to the Return Channel.**

**2 Press this button and hold until the message "RETURN PLUS PROGRAMMED!" appears.**

- When you turn off the TV, the Return Channel setting is cancelled.

**To view the Return Channel:**
Press this button.

- You can view two channels (current channel and Return Channel) alternately by pressing this button.

**To cancel the Return Channel setting:**
Press this button and hold until the message "RETURN PLUS CANCELLED!" appears.

**If no channel is set to the Return Channel:**
You can view the channel selected right before the current channel by pressing this button.

# Viewing teletext programmes

*< S series only >*




## ■ Basic operation

**1 Select a TV channel with a teletext programme.**

**2 Press the TV/TEXT button to change the TV mode to the teletext mode.**

The mode cycles as follows.

TV mode → TEXT mode (TEXT only) → MIX mode (TV and TEXT) → TV mode

**3 Select a teletext page by pressing the CHANNEL –/+ button, Number buttons or coloured buttons.**

To return to the TV mode, press the TV/VIDEO button or the TV/TEXT button.

- If you have trouble receiving teletext broadcasts, consult your local dealer or the teletext station.
- If characters on a teletext programmes do not appear properly, change the TEXT LANGUAGE setting. For details, see "TEXT LANGUAGE" on page 19.

## Using the List Mode

You can store the numbers of your favourite teletext pages in the List mode and call them up quickly using the coloured buttons.

**To store the page numbers:**

**1 Press the MODE button to engage the List mode.**

The stored page numbers are displayed at the bottom of the screen.

**2 Press a coloured button to select a position. Then press the Number buttons to enter the page number.**

**3 Press and hold down the STORE button.**

The four page numbers blink white to indicate that they are stored in memory.

**To call up a stored page:**

**1 Press the MODE button to engage the List mode.**

**2 Press a coloured button to which a page has been assigned.**

To exit the List mode, press the MODE button again.

## REVEAL

Some teletext pages include hidden text (such as answers to a quiz).
You can display the hidden text.

**Each time you press the REVEAL button, text is hidden or revealed.**

## HOLD

You can hold a teletext page on the screen for as long as you want, even while several other teletext pages are being received.

**Press the HOLD button.**

To cancel the HOLD function, press the HOLD button again.

## CANCEL

You can watch a TV programme even when in the teletext mode.

**1 Press the Number button to enter a page number, or press a coloured button.**

The TV starts searching for a teletext page.

**2 Press the CANCEL button.**

The TV programme appears.

When the TV finds the teletext page, its page number appears in the upper left of the screen.

**3 Press the CANCEL button to view the teletext page.**

- Pressing the CANCEL button cannot change the teletext mode to the TV mode.

## INDEX

You can return to the index page instantly.

**Press the INDEX button.**

**In the List mode:**
Returns to the page number displayed in the lower left area of the screen.

## SUBPAGE

Some teletext pages include sub-pages that are automatically displayed.
You can hold any sub-page, or view it at any time.

**1 Press the SUBPAGE button to operate the Sub-page function.**

**2 Press the Number buttons to enter a sub-page number.**

**Example:**

3rd sub-page → press 0, 0, 0 and 3.

- You can also select a sub-page by pressing the red or green button.

To cancel the Sub-page function, press the SUBPAGE button again.

## SIZE

You can double the height of the teletext display.

**Press the SIZE button.**

The teletext display changes cyclically.



# Using the TV's menus

This TV has a number of functions you can operate using the menus. To use all your TV's functions fully, you need to understand how to use the menus.




## ■ Basic operation

**1 Press the MENU ▲/▼ buttons.**
One of the 5 menus is displayed.




**2 Repeatedly press the MENU ▲/▼ buttons to display a desired menu.**

- If you hold down the ▼ button, the next menu is displayed.
- If the selected function is on the first line, pressing the ▲ button displays the preceding menu.

**3 Repeatedly press the MENU ▲/▼ buttons to select a desired function.**

**4 Press the MENU ◀/▶ buttons to change function settings.**

**Example:**




- With some functions, the operation method may differ.

**5 Press the DISPLAY button to turn the display off.**

- To operate a menu using the buttons on the front panel of the TV, refer to "Operating menus" on page 22.

## INPUT

You can view images from VCRs or other devices connected to your TV.

**1 Press MENU ▲/▼ to display the "MENU 1" menu, then select "INPUT".**




**2 Press MENU ◀/▶ to select the VIDEO mode.**

TV mode changes to VIDEO mode.

## PICTURE TILT

*< AV-29 models only >*

There are cases where the Earth's magnetic force may make the picture tilt. If this happens, you can correct the picture tilt.

**1 Press MENU ▲/▼ to display the "MENU 1" menu, then select "PICTURE TILT".**




**2 Continue pressing MENU ◀/▶ until the picture becomes level.**

## VNR

You can reduce picture noise.

**1 Press MENU ▲/▼ to display the "MENU 1" menu, then select "VNR".**




**2 Press MENU ◀/▶ to select "ON".**

To cancel the VNR function, select "OFF".

## COMPRESS (16:9)

This function converts a normal picture (4:3 aspect ratio) into a wide picture (16:9 aspect ratio).
Use for pictures with a 16:9 aspect ratio that have been squeezed into a normal picture (4:3 aspect ratio), to restore their original dimensions.

**1 Press MENU ▲/▼ to display the "MENU 1" menu, then select "COMPRESS (16:9)".**




**2 Press MENU ◀/▶ to select "ON".**



To cancel the COMPRESS (16:9) function, select "OFF".

## AUTO SHUTOFF

You can set your TV to turn off if no signals are received for about 15 minutes or longer after the end of a broadcast.

**1 Press MENU ▲/▼ to display the "MENU 2" menu, then select "AUTO SHUTOFF".**




**2 Press MENU ◀/▶ to select "ON".**

To cancel the AUTO SHUTOFF function, select "OFF".

- The AUTO SHUTOFF function does not turn off the TV's main power.
- The AUTO SHUTOFF will not work for a VIDEO mode.

## CHILD LOCK

You can disable the front control buttons of the TV.
When this function is set to "ON", the TV can be operated using only the remote control.
Use this function to prevent children from operating the TV without parental consent.

**1 Press MENU ▲/▼ to display the "MENU 2" menu, then select "CHILD LOCK".**




**2 Press MENU ◀/▶ to select "ON".**

To cancel the CHILD LOCK function, select "OFF".

- The CHILD LOCK function is canceled when you turn the power off.

## BLUE BACK

You can mute the sound and change the picture into a blue screen while no signals are received by the TV, or when the signals are unstable.

**1 Press MENU ▲/▼ to display the "MENU 2" menu, then select "BLUE BACK".**




**2 Press MENU ◀/▶ to select "ON".**

To cancel the BLUE BACK function, select "OFF".

- To view a broadcast even when the reception signal is poor, set the BLUE BACK function to "OFF".
- Even when the BLUE BACK function is set to "OFF", the sound may not be audible.

## VIDEO-2 SET

Set the VIDEO-2 SET correctly according to the video signal input from the external device connected to the VIDEO-2 terminal. If this setting is incorrect, images will not be displayed.

**1 Press MENU ▲/▼ to display the "MENU 2" menu, then select "VIDEO-2 SET".**




**2 Set the VIDEO-2 SET according to the video signal input from the VIDEO-2 terminal.**

**If a normal video signal (composite video signal) is input:**
Press the MENU ◀/▶ buttons to select "VIDEO".

**If a component video signal ($Y/C_B/C_R$ signals) is input:**
Press the MENU ◀/▶ buttons to select "COMPONENT".

## Picture Adjustments

You can adjust the picture as you like.

**1 Press MENU ▲/▼ to display the "MENU 4" menu.**




**2 Press MENU ▲/▼ to select an item and press MENU ◀/▶ to adjust it.**

| | | |
|---|---|---|
| **TINT*** | - : Reddish | + : Greenish |
| **COLOUR** | - : Lighter | + : Deeper |
| **BRIGHT** | - : Darker | + : Brighter |
| **CONT** | - : Lower | + : Higher |
| **SHARP** | - : Softer | + : Sharper |

* TINT (tint) is displayed only when viewing images from NTSC3.58 or NTSC4.43 colour systems.

## Sound Adjustments

You can adjust the sound as you like.

**1 Press MENU ▲/▼ to display the "MENU 5" menu.**




**2 Press MENU ▲/▼ to select an item and press MENU ◀/▶ to adjust it.**

| | | |
|---|---|---|
| **BASS** | - : Weaker | + : Stronger |
| **TREBLE** | - : Weaker | + : Stronger |
| **BALANCE** | - : Left | + : Right |

## AI VOLUME

You can prevent the sudden increase or decrease of volume that occurs when changing channels or switching VIDEO modes.

**1 Press MENU ▲/▼ to display the "MENU 5" menu, then select "AI VOLUME".**




**2 Press MENU ◀/▶ to select "ON".**

To cancel the AI VOLUME function, select "OFF".

- The AI VOLUME function may not operate as expected if the sound input level from a broadcast station (or video software) is extremely low.
- The AI VOLUME function for TV mode and VIDEO mode can be set separately. For example, you can set it to be off in TV mode and on in VIDEO mode. If you set the AI VOLUME function while viewing a TV channel, the setting is registered as the setting for TV mode. If you set the AI VOLUME function while viewing images from a VIDEO terminal, the setting is registered as the setting for VIDEO mode.

## AUTO CH PRESET

You can automatically preset all TV channels that can be received by your TV to channels.

**1 Press MENU ▲/▼ to display the "MENU 3" menu, then select "AUTO CH PRESET".**




**2 Press MENU ◀/▶ to start the AUTO CH PRESET function.**

">>> ON SEARCH" is displayed on the screen.

When all the TV channels that can be received on your TV have been preset, the display goes out and the AUTO CH PRESET function operation is completed.

**To stop the AUTO CH PRESET:**
Press the MENU ◀/▶ button.

- The AUTO CH PRESET function does not preset a TV channel to the AV channel (channel number 0).
- If the TV cannot preset the TV channel you want to view, preset it manually. For details, see "MANUAL CH PRESET" on page 18.

## MANUAL CH PRESET

You can manually preset desired TV channels to desired channels.

**1 Press MENU ▲/▼ to display the "MENU 3" menu, then select "MANUAL CH PRESET".**




**2 Press MENU ◀/▶.**

The sub-menu is displayed.




- The channel number is displayed as a PR number. For example, channel 1 will be displayed as PR 1. However, the AV channel will be displayed as AV.

**3 Press MENU ◀/▶ to select the channel number.**

**4 Press VOLUME –/+ to start searching for the TV channel.**

"> > >" or "< < <" is displayed on the screen.

When the TV finds a TV channel, the "> > >" or "< < <" display goes out, and the TV channel is preset to the currently selected channel number.

- If the TV channel you want to preset is not displayed, repeat step 4 until the TV finds the TV channel you want to preset.
- To stop the MANUAL CH PRESET function, press any button other than the VOLUME –/+ button.

**If the picture is not clear:**
Fine-tune the TV channel.

**1** Press MENU ▲/▼ to select "FINE".




**2** Hold VOLUME –/+ down to fine-tune the TV channel so that the best image is displayed on screen.

"> " or "< " indicates that the TV is fine-tuning the TV channel.

**If the sound is not clear:**

**1** Press MENU ▲/▼ to select "SOUND SYSTEM".




**2** Press VOLUME –/+ to select the appropriate sound system.

- For the sound systems in each country or region, refer to the table "Broadcasting systems" on the back cover.

**5 Press MENU ▲/▼ to select "MANUAL".**

**6 Repeat steps 3 to 5 if you want to preset another TV channel to a channel.**

## SKIP

You can set undesired channels to be skipped. Channels set to be skipped cannot be selected by the CHANNEL –/+ buttons nor the CHANNEL SCAN button.

- Channels to which TV channels have not been preset are automatically set to be skipped.

**1 Press MENU ▲/▼ to display the "MENU 3" menu, then select "MANUAL CH PRESET".**

**2 Press MENU ◀/▶.**

The sub-menu is displayed.

**3 Press MENU ▲/▼ to select "SKIP".**




**4 Press MENU ◀/▶ to select the channel you want to skip.**

**5 Press VOLUME –/+ to select "YES".**

The channel is set to be skipped.
To cancel the SKIP function, select "NO".

**6 Repeat steps 4 and 5 if you want to set another channel to skip.**

## LANGUAGE

You can select the language for the on-screen display.

**1 Press MENU ▲/▼ to display the "MENU 3" menu, then select "LANGUAGE".**




**2 Press MENU ◀/▶ to select language.**

The on-screen display indications are in the selected language.

## TEXT LANGUAGE

*< S series only >*

You can select one of 5 teletext language groups. Set the teletext language group that corresponds to the language of the teletext programme that you want to watch.

**1 Press MENU ▲/▼ to display the "MENU 3" menu, then select "TEXT LANGUAGE".**




**2 Press MENU ◀/▶ to select a group.**

| Group | languages |
|---|---|
| **Group 1** | English, German, Swedish / Finnish / Danish / Hungarian, Italian, French, Spanish / Portuguese, Turkish |
| **Group 2** | Polish, German, Estonian, Slovenian, Czech / Slovakian, Rumanian |
| **Group 3** | Polish, German, Estonian, Lettish, Russian, Ukrainian |
| **Group 4** | English, French, Turkish, Arabic |
| **Group 5** | English, French, Turkish, Farsi |

- This TV is WST Level 1.0 compatible. Depending on the broadcast, the language set may not display properly.

# TV buttons and parts

## Front

*< AV-29WS3/AV-29WX3 >*




*< AV-29LS2/AV-29LX2 >*




*< AV-25KX3 >*




*< AV-21WS3/AV-21WX3 >*




*< AV-21LS2/AV21LX2/AV-25LS3/AV-25LX3 >*



## TV buttons and parts

*< AV-21DX3 >*




*< AV-20NX3/AV-21FX3 >*




① Headphone jack
② VIDEO-3 terminal
③ MENU button
④ CHANNEL –/+ buttons
⑤ VOLUME –/+ buttons
⑥ TV/VIDEO button
⑦ ECO sensor
⑧ Remote control sensor
⑨ SUB POWER lamp
⑩ POWER lamp
⑪ Main power button

*For AV-25KX3/AV-21DX3/AV-21FX3/AV-20NX3:*
When the main power is switched on, the POWER lamp turns red.
When the TV is turned on (the sub power is on), the SUB POWER lamp turns green.

**Rear**




① VIDEO-1 INPUT terminal
② S/VIDEO-1 INPUT terminal
③ COMPONENT (VIDEO-2) INPUT terminal
④ OUTPUT terminal
⑤ Aerial socket

# Using the buttons on the TV

## Basic operation

- Check to make sure the CHILD LOCK function is set to “OFF”. When the CHILD LOCK function is set to “ON”, the TV cannot be operated using the front control buttons. For details, see “CHILD LOCK” on page 15.

**1 Press CHANNEL –/+ to turn the TV on from standby mode.**

**2 Press CHANNEL –/+ to select a channel.**

**3 Press VOLUME –/+ to adjust the volume.**

**4 To turn your TV off, press the Main power button to turn off the TV’s main power.**

**To change the TV mode to the VIDEO mode:**

- Press the TV/VIDEO button if the TV has one. See page 7.
- If the TV has no TV/VIDEO button, select the VIDEO mode with the INPUT function in “MENU 1”.

## Operating menus

You can operate functions in menus using the front control buttons on the TV.

**1 Press MENU ▼ to display a menu.**

**2 Press MENU ▼ repeatedly to display the menu you want to use.**

**3 Press MENU ▼ to select the desired function or item.**

**4 Press MENU –/+ or VOLUME –/+ to carry out the desired operation.**

For details, see the description for each function.

**5 Press VOLUME –/+ to turn the menu display off.**

**To turn the sub-menu display off:**

1 Press MENU ▼ to select “EXIT”.




2 Press VOLUME –/+ to turn the display off.

# Troubleshooting

If there is no picture or the TV does not operate normally, make sure the problem isn't due to the reasons indicated below.
If the problem persists even after taking the measures indicated, please contact a service technician.

### Cannot turn the TV on

- Press the Main power button on the TV.
- Connect the power cord to the AC outlet.

### The screen turns blue

- Is the BLUE BACK function on? (see page 15.)

### Remote control inoperable

- Replace the batteries. (see page 3.)

### Buttons on front of the TV do not work

- Switch the CHILD LOCK function off. (see page 15.)

### TV does not respond immediately

- Press the main power button on the TV to turn off the main power. Press the main power button again to turn on the TV. If the TV returns to a normal state, operation is normal.

### The TV turns off suddenly

- Is the OFF TIMER function set to operate? (see page 10.)
- Is the AUTO SHUTOFF function on? (see page 15.)

### Poor sound

- Press the SOUND SYSTEM button to select another sound system. (see page 8.)
- Adjust the sound settings. (see page 16.)

*< S series only >*

- If there is noise during mono sound output, press the **I/II** button to select "MONO". (see page 9.)

### Poor picture

- Press the COLOUR SYSTEM button to select another colour system. (see page 8.)
- Adjust the picture settings. (see page 16.)
- Is a component signal output device, such as a DVD player, connected correctly? (see page 5.)
- Is the VIDEO-2 SET function setting correct? (see page 16.)
- If noise (snow) totally blocks out the picture, check the following.
  - Have the TV and aerial been connected properly?
  - Has the aerial cable been damaged?
  - Is the aerial pointing in the right direction?
  - Is the aerial itself faulty?
- If the TV or aerial suffer interference from other equipment, stripes or noise may appear in the picture. Move any equipment which can cause interference away from the TV.
- If the TV or aerial suffer interference from signals reflecting from mountains or buildings, double-pictures (ghosting) will occur. Change the aerial's direction or replace it with an aerial with better directionality.
- When a white and bright still image (such as a white dress) is displayed on the screen, the white part may look as if it is coloured. When the image disappears from the screen, the unnatural colours will also disappear.

### The picture is tilted

*< AV-29 models only >*

- A picture may be tilted due to the influence of the earth's magnetism. In this case, use the PICTURE TILT function to adjust the tilt. (see page 14.)

# Specifications

**TV RF systems**
B, G, I, D, K, K1, M

**Colour systems**
PAL, SECAM, NTSC 3.58 MHz, NTSC 4.43 MHz

**Receiving channels**
VHF low channel (VL), VHF high channel (VH), UHF channel (U)
Receives cable channels in mid band, super band and hyper band.

**External input / output**

| | |
|---|---|
| VIDEO-1: | VIDEO input, AUDIO L/R input,<br>(If your TV has a S-connector ; S-video input) |
| VIDEO-2/COMPONENT: | VIDEO input, AUDIO L/R input,<br>COMPONENT VIDEO ($Y/C_B/C_R$) input |
| VIDEO-3: | VIDEO input, AUDIO L/R input |
| OUTPUT: | VIDEO output , AUDIO L/R output |
| Headphone jack: | stereo mini jack (3.5 mm diameter) |

**Teletext system** < *S series only* >
FLOF (Fastext), WST (World Standard Text)

**Language displayed by teletext** < *S series only* >
Please see the table in the description "TEXT LANGUAGE" on page 19.

**Sound-multiplex systems** < *S series only* >
A2 or NICAM (B/G, I, DK)

***Design and specifications subject to change without notice.***

## Broadcasting systems

| Area | Country or Region | System | |
|---|---|---|---|
| | | Colour | Sound |
| Asia, Middle East | Bahrain, Kuwait, Oman, Qatar, United Arab Emirates, Yemen, etc. Indonesia, Malaysia, Singapore, Thailand, India, etc. | PAL | B/G |
| | China, Vietnam, etc. | PAL | D/K |
| | Hong Kong, etc. | PAL | I |
| | Islamic Republic of Iran, Lebanon, Saudi Arabia, etc. | SECAM | B/G |
| | Philippines, Taiwan, Myanmar, etc. | NTSC | M |
| Europe | Russia, etc. | SECAM | D/K |
| | Czech Republic, Poland, etc. | PAL | D/K |
| | Germany, Holland, Belgium, etc. | PAL | B/G |
| | UK, etc. | PAL | I |
| Oceania | Australia, New Zealand, etc. | PAL | B/G |
| Africa | Republic of South Africa, etc. | PAL | I |
| | Nigeria, etc. | PAL | B/G |
| | Egypt, Morocco, etc. | SECAM | B/G |

**This file has been downloaded from:**

www.UsersManualGuide.com

User Manual and User Guide for many equipments like mobile phones, photo cameras, monther board, monitors, software, tv, dvd, and othes..

Manual users, user manuals, user guide manual, owners manual, instruction manual, manual owner, manual owner's, manual guide, manual operation, operating manual, user's manual, operating instructions, manual operators, manual operator, manual product, documentation manual, user maintenance, brochure, user reference, pdf manual

Downloaded from: https://www.usersmanualguide.com/